


5



Ducati service manual



6



11



1st



12







1st



# QUICK SHIFT HALL FOR DUCATI PANIGALE V2-V2 955-V4-V4S-V4R-1299

## LIMITATIONS



## MAINTENANCE

